



FLAKER, SELF CONTAINED FM-120KE-50-HC

Product series: FM

Item number: F115-C127

This Hoshizaki FM-120KE-50-HC is a self contained flake ice maker producing up to 125 kg of high-quality flake ice per 24 hours.

Hoshizaki ice makers generate quality granular ice, such as Flake ice. The light texture of granular ice has a quick cooling effect, creating an environment of uniform temperatures, without causing unpleasant freezer burn. This is why Hoshizaki Flake ice is highly popular and considered the ideal material to prepare and layer attractive food displays. For flake ice, the extruding head is equipped with wide channels and multi-blade cutters.

Sustainable

The FM-120KE-50-HC uses refrigerant R290. This natural refrigerant is not only climate-friendly, but also boosts the machine, when it comes to performance and production capacity.

Material

The exterior is made of stainless steel and the closed water circuit provides maximum protection against any type of contamination during the entire ice production process. All Hoshizaki machines are easy to use, clean and maintain.

Unique Technology

The FM series has a worktime-based replacement system, which can be monitored with an intuitive control display for preventive maintenance. Hoshizaki was the first to introduce an automated water circuit rinse cycle, to avoid harmful mineral residues from clogging the hydraulic system and maintaining top sanitary conditions.

Smart Design

Like all Hoshizaki Ice makers, the FM-120KE-50-HC is designed to last and comes with smart design extras. The Flaker uses carbon graphite bushings instead of conventional ball bearings allows the machine to work entirely without grease. Here, the absence of moving parts prevents wear and tear, while the water-lubricated bearings protect the system from unpleasant calcification and bacterial contamination.

Perfect Fit

With outside dimensions W x D x H of mm, the FM-120KE-50-HC is compact and makes a perfect fit for small spaces.

Plug&Play

The smart plug-and-play design guarantees an easy and quick set-up.



SPECIFICATIONS

Product title	Flaker, Self Contained	Refrigerant	R290
Production Capacity (kg/24h) approx. (AT 10°C, WT 10°C)	125	CO2 equivalent (kg)	0.3
Storage bin capacity (kg) approx.	57	Cooling System	Air Cooled
Power supply	1/220 - 240V/50Hz	Product configuration	Self Contained
Electric Consumption (kW)	0.355	Net weight (kg)	76
Ice type	Flake	Gross Weight Packed (kg)	88





LABORATORY EQUIPMENT MAINTENANCE, REPAIR, CALIBRATION AND SALES

Established in 1987, Henderson Biomedical is the UK's leading laboratory equipment sales and service provider. Our knowledgeable team can provide you with excellent sales advice on a range of different types of laboratory equipment including centrifuges, refrigerators, freezers and heat sealers.

Henderson Biomedical is also able to provide you with first class after-sales service and calibration of your laboratory equipment. We are an **ISO 17025 (UKAS) accredited calibration test laboratory** and our team of Field Service Engineers cover the whole of the United Kingdom.

Please contact us for more information on the types of equipment we supply and the different after-sales services we can offer.

Henderson Biomedical

Unit 3, Swan Close
Croydon CR0 2DZ
United Kingdom

Tel: 020 8663 4610

**For sales enquiries: sales@henderson-biomedical.co.uk
For all other enquiries: info@henderson-biomedical.co.uk
www.henderson-biomedical.co.uk**

